
## Synthetic Leather











- Abrasion Resistant to over 100,000 cycles (AS2001.2.25-2006)
- Flame Retardant compliant with Australian and International standards (AS3744.1-1998, AS3744.2-1998 & BS5852-2006)
- UV Resistant/Stabilised (AS4878.10-2001 & AS1441.8-1973)
- Hydrolysis Resistant (ASTM D3690.7.11)

- -Tear Resistant (AS2001.2.10-1986)
- Anti-Bacterial/Anti-Microbial Treated
- Easy Maintenance
- Supple Leather Soft Comfort
- 3 year warranty

## FABRIC CARE AND MAINTENANCE

All PVC and PU Synthetic Leather fabrics require a degree of maintenance and care. A regular, minimum weekly cleaning regimen with appropriate products will prolong the life of the upholstery.

We recommend the following cleaning procedure:

- Remove any loose dirt or soiling with a suitable cloth (eg microfibre) or soft bristled brush and lukewarm water.
- Apply a mild, lukewarm pH neutral soap solution with a sponge of soft bristled brush.
- Allow the soap to stand briefly, but not to dry.
- Remove soap residue with microfibre cloth and clean water.
- Dry thoroughly with dry microfibre cloth.

Do not use abrasive cleaners, steel wool or cleaners containing solvents, gasoline, petroleum distillates, plasticisers or concentrated bleach. These have the potential to damage the fabric surface and void the guarantee.





